



Dineen Sales Ltd.

Wolfhill, Athy, Co. Kildare.

Tel: (059) 8635557. Fax: (059) 8635655. www.dineensales.com

How To Mix Vermiculite Concrete

Materials needed:

- 1 No. 100 litre bag of DINEEN Vermiculite (approx. 6 parts by volume).
- 18kg of Portland cement or [Cement Fondu](#) (approx. 1 part by volume)
- 23 litres (5 gallons) of water.

This mix (6:1) will make about 0.1m³ of lightweight concrete.

For 8:1 use 14kgs of Cement



Pour vermiculite from the bag into mixer, add the correct proportion of Portland cement, mix together and add the water - do not make or use a sloppy mix.

The vermiculite concrete can then be placed and lightly tamped into position. Do not compact heavily.